Metal Roofing | Metal Walls | Custom Fabrication

# **CMP MAINTENANCE MANUAL & CARE GUIDE**



Statesville, NC | Myrtle Beach, SC | Charleston, SC 704-871-8704 | questions@cmpmetalsystems.com www.cmpmetalsystems.com

Metal Roofing

Metal Walls

Sustom Fabrication



With a little care and attention during service, your CMP Roof System will provide an extended service of life. While durable, factory-applied finishes for metal panels will last many years longer than ordinary paints, they should be cleaned thoroughly on a routine basis whenever the finish is not washed by rain. We recommend that you follow our simple maintenance schedule. By following our recommendations you will be assured of the maximum trouble-free lifespan of you building.

Periodic maintenance of the exterior will depend on the location of your building.

The following table gives recommended periods but can be varied to suit particular environments based on local or practical experience.

Building Location	Maintenance Period			
(a) Up to 5 km from the sea	2 Months			
(b) HighPollutionindustrialarea	2 Months			
(c) Mediumpollutionindustrialarea	3 Months			
(d) Areasofhighhumidity	4 Months			
(e) Lowpollutionindustrialarea	6 Months			
(f) Dry,desertareas	8 Months			

Preventive maintenance should commence immediately after a project is erected, modified, or repaired.

#### **INSPECTION:**

- 1. Check for any debris that may have been left on top of panel or trim. Examples of this are ferrous items such as screws, pop rivets, nails, drill sward, sheet metal off-cuts, tin cans, etc. Large or heavy items should be removed by hand to avoid damaging the paint or zinc layer on the panel. The remaining smaller items may be swept off with a soft nylon brush. Please note this check should be made after any trade has worked on the building, e.g., electricians, plumbers, air conditioning technicians, and steel erectors.
- 2. Check for sand or dirt build up. These retain salt and moisture and will rapidly breakdown the paint and zinc layers resulting in corrosion of the base metal.

Metal Roofing

Metal Walls

Custom Fabrication



- 3. The most vulnerable areas of the building are:
- a. Gutters
- b. Roof Sheets
- c. Sheltered Areas.
- d. Top portion of walls sheltered by roof overhangs or gutters.
- 4. Sand and dirt should be washed off with clean desalinated water and a soft nylon brush. Clean from top to bottom and give a final rinse with desalinated water when completed. Ensure no water is trapped anywhere. See the cleaning section for detailed instructions.
- 5. Check the base of wall panels to ensure the ground level is at least 150mm below the bottom of the panel. If wind-blown sand has built up at the base of the wall, it should be removed. If plants/ shrubs etc. are around the building, make sure they are not touching the wall panel, particularly thorn-type bushes.
- 6. Check all high-traffic areas of the roof where maintenance personnel repeatedly traverse the roof surface. Foot traffic can be a major cause of damage. If traffic on the roof is routine, consider installing a walkway to protect the panels.
- 7. Check all equipment, which is located through or adjacent to any panel (Roof or Wall). Ensure there is no moisture buildup on or near the panel. If there is, then corrosion is inevitable. If this condition exists, then make modifications to avoid it. The following situations are examples of conditions to be avoided.
- a. Water run-off from water services or air conditioners.
- b. Copper pipes fastened directly to the steel panel.
- c. Open water storage tanks or ponds adjacent to the panel.
- d. Steam outlets adjacent to the panels.
- e. Acid storage areas adjacent to the panels.
- 8. Standard gutters and Valley gutters.
- a. Regular checks should be made and all rubbish and sand should be removed.
- b. Flush the gutters with water
- c. Check that the downspouts are clear.
- d. Check that downspouts have adequate drainage away from the building.
- 9. If minor damage occurs to the sheeting or trims, and a paint touch-up is required, then the following procedure should be followed:

Metal Roofing

Metal Walls

Custom Fabrication



- a. Abrade the affected area.
- b. Clean down with a solvent.
- c. If based metal is exposed, apply one coat of a zinc chromate primer. If base metal is not exposed then the primer is not required.
- d. Apply one coat of available touch-up paint.

#### **CLEANING:**

Cleaning restores the appearance of the panels, making repainting unnecessary, and maintaining a pleasing appearance, as well as removing the buildup of corrosive materials. Applications requiring maintenance cleaning often include soffits, siding under eaves, and the undersides of eave gutters.

In many cases, washing the painted surface with clean water from a garden hose will remove most of the dirt and accumulated deposits. Ideally, washing should be done at least every six months and more frequently in coastal areas where marine salt spray washing is ineffective in cleaning stubborn dirt, mild detergents, or household ammonia solutions can be used as described below. In all cases, test a small unobtrusive area for color-fastness before cleaning large areas.

- Use one cup of Tide® (or other common detergent containing less than 0.5% phosphate) dissolved in five gallons of warm water. NOTE: Detergents containing greater than 0.5% phosphate are not recommended for use in general cleaning of building panels.
- OR use one cup of household ammonia dissolved in five gallons of water at room temperature. Never mix ammonia with any kind of bleach.
- Never blend cleaners and bleach yourself. If bleach and detergent are required, use detergents containing bleach.

Using either solution, work from the top to the bottom of panels with a well-soaked soft cloth, sponge, brush with very soft bristles, or low-pressure spray washer to clean the surface. Washing from the top down avoids streaking. Application should be gentle to prevent shiny spots. Scouring powders or industrial solvents are not recommended, since they may damage the paint film.

Metal Roofing

Metal Walls

Custom Fabrication



Solvent-containing cleaners such as Fantastic® are very effective and can be used. If mildew or other fungal growth is a problem and cannot be removed as described above, detergent containing bleach, such as Tide® with Bleach, is recommended. The surface should be thoroughly rinsed with water after cleaning to remove traces of detergent. If the building is in an area of industrial pollution or close to a marine environment then water alone may not be enough. Salts and other deposits build up at the formed corners of panels and quickly break down hardness of the layer increases making removal more difficult. In this case, the period between maintenance operations should be shortened and a mild detergent should be added to the initial washing water.

#### **SOLVENTS:**

CAUTION: Solvent and abrasive type cleaners as they can do more harm than good by wearing both the paint and zinc layers. Only use when cleaning solution listed above is ineffective. Most organic solvents are flammable and/or toxic and must be handled accordingly. Keep away from open flames, sparks and electrical motors. Use adequate ventilation, protective clothing, and goggles. Solvents that may be used to remove non-water soluble deposits (tar, grease, oil, paint, graffiti, etc.) from fluoropolymer surfaces include:

#### A. Alcohols

- Denatured alcohol (ethanol)
- Isopropyl (rubbing alcohol)
- Methanol (wood alcohol)

#### B. Petroleum Solvents and Turpentine

- VM&P Naphtha
- Mineral Spirits
- Kerosene
- Turpentine (wood or gum spirits)

The above alcohols and solvents have no permanent effect on fluoropolymer painted surfaces.

#### C. Aromatic and Chlorinated

- Xylol (Xylene)
- Toluol (Toluene)

Metal Roofing

Metal Walls

Custom Fabrication



- Perchloroethylene (Perclene)
- Trichlorethylene (Triclene)

The above solvents should be used with caution on any fluoropolymer painted surfaces. Limit contact of the fluoropolymer surface with solvent to five minutes maximum and test the effects of the solvent on a small area before using over the entire surface.

#### D. Ketones, Esters, Lacquer, Thinner, Paint Remover

- Methyl Ethyl Ketone (MEK)
- Methyl Isobutyl Ketone (MIBK)
- Ethyl Acetate (Nail Polish Remover)
- Butyl Acetate
- Lacquer Thinner
- Paint Remover (non-flammable)
- Acetone (do not use acetone on painted surfaces)

The above solvents should be used very cautiously on a fluoropolymer painted surface. Limit contact of the fluoropolymer surface with solvent to one minute maximum and test the effects of the solvent on a small area before using over the entire surface. Note: There are many formulations of paint remover on the market. It is possible that some may remove the fluoropolymer surface. Proceed very cautiously in use of any paint remover. Metal supplier and coating manufacture are not responsible for damage from unrestricted use.

#### E. Chemical Solutions

- Sodium Hypochlorite Solution (Laundry Bleach, Clorox)
- Hydrochloric Acid (Muriatic Acid)
- Oxalic Acid
- Acetic Acid (Vinegar)

Hydrochloric or muriatic acid, diluted with ten volumes of water, may assist in removing rust stains from fluoropolymer surfaces. Limit contact to five minutes. Caution: acid solutions are corrosive and toxic. Flush all surfaces with copious amounts of water after use. Oxalic acid solution or vinegar may be used for the same purpose. Flush with water.

Metal Roofing | M

Metal Walls

Custom Fabrication



#### **GRAFFITI:**

Graffiti presents a special problem because of the many possible agents used, generally aerosol paint. It is best to try the less active solvents first (Solvent Group A, B, C) and then the stronger solvents (Solvent Group D). If none of these are satisfactory, it may be necessary to resort to touchup, repaint, or replacement, depending on the extent of the damage.

#### **WARRANTY:**

Misuse of any of the cleaning agents listed above will result in a voiding of warranty for the surface affected.

#### **ROOF SAFETY:**

Extreme caution should be exercised when working on roofs.

- Use only ladders, which are long enough to reach one meter above the stepoff point.
- Always secure the ladder to the building and make sure it is on a firm base.
- Do not step on skylight panels.
- When walking on the roof, step on the low corrugations, not on the high corrugations.
- Stepping on the high corrugations can damage the sheets. Walk along the screw line where possible.



## 29/26 GAUGE COLOR CHART

#### Construction Metal Products inc.

CMP manufactures a variety of metal roof and wall panels in 26 gauge and/or 29 gauge material. Please see the back of this chart to view the profiles that are available.

CMP's 40-year Silicon Polyester paint system, with Cool Roof Technology, provides solar reflectance ratings to meet today's Energy Star requirements. The 40-year paint system and galvalume steel guarantees a winning combination of weather-tested paint performance and superior corrosion resistance.





Colors shown here are as accurate as the printing process permits. Slight variations should be expected for the actual coil product.






### **CMP MULTI-RIB**

CMP MULTI-RIB Design Is Unmatched In Performance Durability.




### CMP R-PANEL

A Superior Roof or Wall Panel with Maximum Strength.



### CMP 5-V

The 5-V's Stunning Design Makes it Very Popular with Residential and Commercial Customers.



### CMP NAIL STRIP

Revolutionary Design Eliminates the need for Through Fasteners. (26 GA and 24 GA)



#### SAFETY PRECAUTIONS

Gloves should be worn to prevent injury while handling steel panels. Safety glasses should be worn to prevent eye injury when cutting or drilling steel panels with power tools. Use care when walking, sitting, or kneeling on a steel roof to avoid a fall. Steel panels may become slippery when wet. Do not work on the steel panels when wet or when climatic conditions are not suitable for safe installation. Failure to comply with these procedures relieves the manufacturer of responsibility for any resultant damage to or deterioration of the product and VOIDS ALL WARRANTIES. THERE IS NO IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PURPOSE.



The Solar Reflective Index (SRI) as per ASTM E1980 is noted next to each color name. All colors are direct deposit paint samples.

Do not use this sheet to color match. Call your representative for a painted metal sample.



 $\label{lem:colors} {\it Custom colors and/or color matching is available subject to minimum volume criteria.} \\ {\it Pricing will be dependent on project requirements.} \\$ 

In testament to the high quality of ColorKlad and AlumaKlad, a written warranty is available upon request, for qualifying applications. Available at no charge, this warranty covers peeling, color fade, chaiking and paint integrity. Reference actual warranty for details and conditions. Check suitability or use in potentially corrosive atmospheres. "Acrylic AZ55 is not covered under the ColorKlad® warranty. Metallics and Premiums may be priced higher than standard colors.







ColorKlad® — available in a premium cool coating — is the field-proven, time-tested leader in metal roofing. ColorKlad is made of a PVDF coating containing 70% Kynar 500® or Hylar 5000® resin over a high-quality primer, permanently bonded to commercial quality, extra smooth Grade 50 AZ50 Galvalume® or Galvanized G90 sheet or coil.

AlumaKlad™ — available in a premium cool coating — maintains design integrity and attractive appearance when design, climatic and/or atmospheric conditions call for aluminum. AlumaKlad is made of a PVDF coating containing 70% Kynar 500® or Hylar 5000® resin over a high-quality primer, permanently bonded to 3105-H24 aluminum sheet or coil.

COOL COLORS	SRI	24ga		.032"		.040"	.050"	.063"
		20"	48"	20"	48"	48"	48"	48"
AZ55 Acrylic Galvalume*		•	•					
Aged Copper	53	•	•	•	•			
Almond	78		•	<b>A</b>	•	•	•	
Ash Gray	32	•	•					
Bone White	83	<b>A</b>	•	<b>A</b>	•			
Charcoal Gray	29	•	•	•	•			
Classic Green	30	•	•	<b>A</b>	•	•		
Colonial Red	34	<b>A</b>	•					
Dark Bronze	25	•	•	•	•	•	•	•
Dove Gray	54	•	•	•	•			
Mansard Brown	26	•	•	<b>A</b>	•	•	•	
Musket Gray	32	•	•					
Black	-1	•	•	•	•			
Medium Bronze	31	•	•	•	•	•	•	•
Patina Green	55	<b>A</b>	•					
Regal White	78	<b>A</b>	•	•	•			•
Sandstone	71	<b>A</b>	•			•	•	
Sierra Tan	30	•	•	•	•	•	•	
Slate Blue	29	<b>A</b>	•					
Slate Gray	40	•	•	•	•			
Snowdrift	93	•	•	•	•			
Stone White	82	•	•	•	•	•		
Terra Cotta	37	<b>A</b>	•					
Premium / Metallic								
Banner Red	43	<b>A</b>	•					
Bright Silver	61	•	•	•	•	•	•	
Copper Penny	45	•	•	•	•			
Hartford Green	24	•	•				•	
Preweathered	39	•	•	•	•			
Royal Blue	26	•	•	•	•			

Items marked with (▲) are available but will be specially processed from 48.375" master coil and the drop coil will ship as part of order.





Metal Roofing | Metal Walls | Custom Fabrication

### FIND OUT MORE ABOUT CMP



704-871-8704



questions@cmpmetalsystems.com



2204 West Front Street Statesville, NC 28677



www.cmpmetalsystems.com



www.facebook.com/ConstructionMetalProducts